

SECTION 10260
MISCELLANEOUS MANUFACTURED SPECIALTIES

PART 1 - GENERAL

1.1 SUMMARY

- .1 Provide fire extinguishers in recessed enclosures in walls as indicated and specified. Install at accessible height, not more than 1219 mm (4'-0") above finished floor. Do not compromise required fire separation or rating. Refer to Mechanical Drawings for products.
- .2 Provide corner guards as indicated and specified.
- .3 Provide walk off mats inside exterior doors except at Mech/Elect 103.

PART 2 - PRODUCTS

2.1 CORNER GUARDS AND WALL PROTECTION

- .1 Corner Guards to be 2" wide, +/- 18" long. Manufactured from rigid PVC extrusions, nominal wall thickness 2 mm (0.078"), with matte pebble grain surface and chemical and stain resistance, c/w retainer clips of continuous extruded aluminum complete with attachment hardware, secured at 457 mm (18") o. c. maximum. Colour selection from the manufacturer's standard colour range. Lengths of corner guards shall be as detailed, complete with matching end caps. Manufacturers: Acrovyn (604-888-3114), Balco Inc. (1-800-767-0082) or Pawling Corporation (1-800-431-3456) or approved alternative. Confirm locations with Consultant prior to ordering and installing.

2.2 WALK-OFF MATS

- .1 Location: inside exterior doors, except at Mech/Elect 103. Surface-mounted low-density polyethelene hinge mat, Arden Model M-750RT with rubber inserts in frame type F-5.

PART 3 - EXECUTION

3.1 INSTALLATION

- .1 Ensure that equipment and material supplied to the site is installed in accordance with manufacturer's printed instructions.
- .2 Use concealed fasteners wherever possible and to suit the intended use, compatible with all surfaces.
- .3 Exposed fasteners shall be tamperproof.
- .4 Secure accessories to blocking or studs in the wall.
- .5 Install wall and corner guards using manufacturer s recommended anchoring devices to effectively secure retainers to walls and corners. Hand pressure lock wall and corner guards over retainers to provide for a free floating action to absorb heavy impact without damage to guard, retainer or adjacent wall.
- .6 Install corner guards straight and true to lengths detailed, from top of base. Do not remove protective coating until guards are installed and after final clean up.

END OF SECTION